

# X20(c)AO4622

Data sheet 3.28 (September 2025)



#### **Publishing information**

B&R Industrial Automation GmbH B&R Strasse 1 5142 Eggelsberg Austria

Telephone: +43 7748 6586-0

Fax: +43 7748 6586-26

office@br-automation.com

### Disclaimer

All information in this document is current as of its creation. The contents of this document are subject to change without notice. B&R Industrial Automation GmbH assumes unlimited liability in particular for technical or editorial errors in this document only (i) in the event of gross negligence or (ii) for culpably inflicted personal injury. Beyond that, liability is excluded to the extent permitted by law. Liability in cases in which the law stipulates mandatory unlimited liability (such as product liability) remains unaffected. Liability for indirect damage, consequential damage, business interruption, loss of profit or loss of information and data is excluded, in particular for damage that is directly or indirectly attributable to the delivery, performance and use of this material.

B&R Industrial Automation GmbH notes that the software and hardware designations and brand names of the respective companies used in this document are subject to general trademark, brand or patent protection.

Hardware and software from third-party suppliers referenced in this document is subject exclusively to the respective terms of use of these third-party providers. B&R Industrial Automation GmbH assumes no liability in this regard. Any recommendations made by B&R Industrial Automation GmbH are not contractual content, but merely non-binding information for which no liability is assumed. When using hardware and software from third-party suppliers, the relevant user documentation of these third-party suppliers must additionally be consulted and, in particular, the safety guidelines and technical specifications contained therein must be observed. The compatibility of the products from B&R Industrial Automation GmbH described in this document with hardware and software from third-party suppliers is not contractual content unless this has been separately agreed in individual cases; in this respect, warranty for such compatibility is excluded in any case, and it is the sole responsibility of the customer to verify this compatibility in advance.

1247782281300-3.28

### 1 General information

### 1.1 Other applicable documents

For additional and supplementary information, see the following documents.

### Other applicable documents

Document name	Title
MAX20 X20 System user's manual	

### 1.2 Coated modules

Coated modules are X20 modules with a protective coating for the electronics component. This coating protects X20c modules from condensation and corrosive gases.

The modules' electronics are fully compatible with the corresponding X20 modules.

For simplification purposes, only images and module IDs of uncoated modules are used in this data sheet.

The coating has been certified according to the following standards:

- · Condensation: BMW GS 95011-4, 2x 1 cycle
- Corrosive gas: EN 60068-2-60, method 4, exposure 21 days







### 1.2.1 Starting temperature

The starting temperature describes the minimum permissible ambient temperature in a voltage-free state at the time the coated module is switched on. This is permitted to be as low as -40°C. During operation, the conditions as specified in the technical data continue to apply.



### Information:

It is important to absolutely ensure that there is no forced cooling by air currents in the closed control cabinet, e.g. due to the use of a fan or ventilation slots.

### 1.3 Order data

Order number	Short description
	Analog output modules
X20AO4622	X20 analog output module, 4 outputs, 10 V or 0 to 20 mA / 4 to 20 mA, 13-bit converter resolution
X20cAO4622	X20 analog output module, coated, 4 outputs, 10 V or 0 to 20 mA / 4 to 20 mA, 13-bit converter resolution
	Required accessories
	Bus modules
X20BM11	X20 bus module, 24 VDC keyed, internal I/O power supply connected through
X20BM15	X20 bus module, with node number switch, 24 VDC keyed, internal I/O power supply connected through
X20cBM11	X20 bus module, coated, 24 VDC keyed, internal I/O power supply connected through
	Terminal blocks
X20TB12	X20 terminal block, 12-pin, 24 VDC keyed

Table 1: X20AO4622, X20cAO4622 - Order data

#### **General information**

### 1.4 Module description

The module is equipped with 4 outputs with 13-bit, including sign, digital converter resolution. It is possible to select between the current and voltage signal using different terminals.

### Functions:

Analog outputs

### **Analog outputs**

The module is equipped with analog outputs with a configurable current and/or voltage signal.

## 2 Technical description

### 2.1 Technical data

Order number	X20AO4622	X20cAO4622	
Short description			
I/O module	4 analog outputs ±10 V or 0 to 20 mA / 4 to 20 mA <sup>1)</sup>	4 analog outputs ±10 V or 0 to 20 mA / 4 to 20 mA	
General information			
B&R ID code	0x1BA3	0xE212	
Status indicators	I/O function per channel, op	perating state, module status	
Diagnostics		·	
Module run/error	Yes, using LED status	indicator and software	
Channel type		g software	
Power consumption		5	
Bus	0.0	01 W	
Internal I/O	1.8 W (Rev. ≥J0), 2.2 W (Rev. <j0)< td=""><td>1.8 W</td></j0)<>	1.8 W	
Additional power dissipation caused by actuators (resistive) [W]		_	
Certifications			
CE		'es	
UKCA		'es	
ATEX	IP20, Ta (see X2	c nA nC IIA T5 Gc :0 user's manual) NTEX 0083X	
UL		E115267 trol equipment	
HazLoc	Process cont for hazardo	s 244665 rol equipment ous locations s, Groups ABCD, T5	
DNV	Class I, Division 2, Groups ABCD, T5  Temperature: B (0 to 55°C)  Humidity: B (up to 100%)  Vibration: B (4 g)  EMC: B (bridge and open deck)		
CCS	Yes	-	
LR	ENV1		
KR	Υ	'es	
ABS	Υ	'es	
BV	Tess  FES3B  Temperature: 5 - 55°C  Vibration: 4 g  EMC: Bridge and open deck		
KC	Yes	-	
Analog outputs			
Output	±10 V or 0 to 20 mA / 4 to 20 mA, via different terminals <sup>1)</sup>	±10 V or 0 to 20 mA / 4 to 20 mA, via different terminals	
Max. output current		oltage >5 V	
Digital converter resolution			
Voltage	±12	2-bit	
Current	12	-bit	
Conversion time	300 μs for	all outputs	
Settling time on output change over entire range		0 μs	
Switch on/off behavior	Internal enable	relay for startup	
Max. error <sup>2)</sup>		· ·	
Voltage			
Gain	±0.0	08% <sup>3)</sup>	
Offset		05% <sup>4)</sup>	
Current			
Gain	±0.0	99% 3)	
Offset		05% <sup>4)</sup>	
Output protection		cuit proof	
Output format	3.10. 0 0.1		
•	INT 0x8001 - 0x7FFF / 1 LSB = 0x0008 = 2.441 mV		
Voltage	·		
Voltage Current	·	LSB = 0x0008 = 2.441 mV LSB = 0x0008 = 4.883 μA	
Voltage	INT 0x0000 - 0x7FFF / 1		

Table 2: X20AO4622, X20cAO4622 - Technical data

### **Technical description**

Order number	X20AO4622	X20cAO4622			
Short-circuit proof	Current limiting ±40 mA				
Output filter	First-order low-pass filte	First-order low-pass filter / cutoff frequency 10 kHz			
Max. gain drift					
Voltage	±0.015	5%/°C <sup>3)</sup>			
Current	±0.02	%/°C <sup>3)</sup>			
Max. offset drift		<del>-</del> -			
Voltage	±0.032	2%/°C <sup>4)</sup>			
Current	±0.032	2%/°C <sup>4)</sup>			
Error caused by load change					
Voltage	Max. 0.11%, from 10	$M\Omega \rightarrow 1 \text{ k}\Omega$ , resistive			
Current	Max. 0.5%, from 1	$\Omega \rightarrow 600 \Omega$ , resistive			
Nonlinearity	<0.007% 4)	<0.005% 5)			
Insulation voltage between channel and bus	500	O V <sub>eff</sub>			
Electrical properties					
Electrical isolation	Channel isolo	ated from bus			
	Channel not isolo	ated from channel			
Operating conditions					
Mounting orientation					
Horizontal	Yes				
Vertical	Yes				
Installation elevation above sea level					
0 to 2000 m	No limitation				
>2000 m	Reduction of ambient temperature by 0.5°C per 100 m				
Degree of protection per EN 60529	IP20				
Ambient conditions					
Temperature					
Operation					
Horizontal mounting orientation	-25 to 60°C (Rev. ≥ J0), 0 to 55°C (Rev. < J0)	-25 to 60°C			
Vertical mounting orientation	-25 to 50°C (Rev. ≥ J0), 0 to 50°C (Rev. < J0)	-25 to 50°C			
Derating	See section	n "Derating".			
Starting temperature	-	Yes, -40°C			
Storage	-40 t	o 85°C			
Transport	-40 to	o 85°C			
Relative humidity					
Operation	5 to 95%, non-condensing	Up to 100%, condensing			
Storage	5 to 95%, no	n-condensing			
Transport	5 to 95%, non-condensing				
Mechanical properties					
Note	Order 1x terminal block X20TB12 separately. Order 1x bus module X20BM11 separately.	Order 1x terminal block X20TB12 separately. Order 1x bus module X20cBM11 separately.			
Pitch	12.5+	<sup>0.2</sup> mm			

Table 2: X20AO4622, X20cAO4622 - Technical data

- 1) 2) 4 to 20 mA: Starting with upgrade version 1.0.2.0 and hardware revision "I0"  $\,$
- At 25°C
- 3) Based on the current output value.
- Based on the entire output range.
- Based on the output range.

### 2.2 LED status indicators


For a description of the various operating modes, see section "Additional information - Diagnostic LEDs" in the X20 system user's manual.

Figure	LED	Color	Status	Description
	r	Green	Off	No power to module
			Single flash	RESET mode
			Double flash	BOOT mode (during firmware update) <sup>1)</sup>
			Blinking	PREOPERATIONAL mode
G 1 2			On	RUN mode
0 4 3 4	е	Red	Off	No power to module or everything OK
4			On	Error or reset status
X20	e + r	Red on / Green	n single flash	Invalid firmware
×	1 - 4	Orange	Off	Value = 0
			On	Value ≠ 0


Depending on the configuration, a firmware update can take up to several minutes.

### 2.3 Pinout


The individual channels can be configured for either current or voltage signals. The type of signal is also determined by the terminals used.



### 2.4 Connection example



### 2.5 Output circuit diagram




### 2.6 Derating


To ensure proper operation, the following points must be taken into account:

- · The derating values listed below must be taken into account.
- In mixed operation with one current output, the mean value of both derating curves must be applied.
- In mixed operation with 2 or 3 current outputs, the derating of the current outputs must be applied.

### Horizontal mounting orientation



### Vertical mounting orientation



### **3 Function description**

### 3.1 Analog outputs

The module is equipped with 4 analog outputs.

The individual channels are designed for current and voltage signals. The differentiation is made by different terminal connections; because of different adjustment values for current and voltage, the output signal must be selected. The following output signals can be set:

- ±10 V voltage signal (default)
- 0 to 20 mA current signal
- 4 to 20 mA current signal



### Information:

The register is described in "Setting the channel type" on page 13.

### 4 Commissioning

### 4.1 Using the module on the bus controller

Function model 254 "Bus controller" is used by default only by non-configurable bus controllers. All other bus controllers can use other registers and functions depending on the fieldbus used.

For detailed information, see section "Additional information - Using I/O modules on the bus controller" in the X20 user's manual (version 3.50 or later).

### 4.1.1 CAN I/O bus controller

The module occupies 1 analog logical slot on CAN I/O.

### 4.2 Optimizing the transfer of analog values

The appropriate function model must be selected for optimal transfer of analog values.


### Function model 0: I/O without jitter (standard)

With a minimum cycle of  $\geq$ 400  $\mu$ s, the corrected values are output in the next cycle. This reduces jitter to a minimum.

### Function model 1: I/O with fast response

With a minimum cycle of  $\geq$ 400  $\mu$ s, the corrected values are output in the same cycle (optimized response).

### The two function models compared



X20(c)AO4622 Data sheet V 3.28

### **5 Register description**

### 5.1 General data points

In addition to the registers described in the register description, the module has additional general data points. These are not module-specific but contain general information such as serial number and hardware variant.

General data points are described in section "Additional information - General data points" in the X20 System user's manual.

# 5.2 Function model 0 - Standard and function model 1 - I/O with fast response

Register	Name	Data type Read		Wr	Write	
			Cyclic	Acyclic	Cyclic	Acyclic
<b>Analog signal</b>	- Configuration					
18	ConfigOutput01 (channel type)	USINT		•1)		•
<b>Analog signal</b>	- Communication					
0	AnalogOutput01	INT			•	
2	AnalogOutput02	INT			•	
4	AnalogOutput03	INT			•	
6	AnalogOutput04	INT			•	

<sup>1)</sup> Starting with upgrade version 1.5.0.0 and hardware revision "N0"

### 5.3 Function model 254 - Bus controller

Register	Offset <sup>1)</sup>	Name	Data type	Read		Write	
				Cyclic	Acyclic	Cyclic	Acyclic
<b>Analog signal</b>	- Configuratio	n					
18	-	ConfigOutput01 (channel type)	USINT		<b>●</b> 2)		•
Analog signal	Analog signal - Communication						
0	0	AnalogOutput01	INT			•	
2	2	AnalogOutput02	INT			•	
4	4	AnalogOutput03	INT			•	
6	6	AnalogOutput04	INT			•	

<sup>1)</sup> The offset specifies the position of the register within the CAN object.

<sup>2)</sup> Starting with upgrade version 1.5.0.0 and hardware revision "NO"

### 5.4 Analog outputs

The individual channels can be configured for either current or voltage signals. The type of signal is also determined by the terminals used.

### 5.4.1 Output values of the analog outputs

Name:

AnalogOutput01 to AnalogOutput04

The normalized output values are specified via these registers. After a permissible value is transferred, the module outputs the corresponding current or voltage.

Data type	Values	Information
INT	-32768 to 32767	Voltage signal -10 to 10 VDC
	0 to 32767	Current signal 0 to 20 mA
	0 to 32767	Current signal 4 to 20 mA <sup>1)</sup>

<sup>1)</sup> Starting with upgrade version 1.0.2.0 and hardware revision "IO"

### 5.4.2 Setting the channel type

Name:

ConfigOutput01

The channel type of the outputs can be defined in this register.

Data type	Values	Bus controller default setting
USINT	See the bit structure.	0

#### Bit structure:

Bit	Description	Value	Information
0	Channel 1	0	Voltage signal (bus controller default setting)
		1	Current signal, measurement range corresponding to bit 4
3	Channel 4	0	Voltage signal
		1	Current signal, measurement range corresponding to bit 7
4	Channel 1: Current measurement range	0	0 to 20 mA current signal
		1	4 to 20 mA current signal
7	Channel 4: Current measurement range	0	0 to 20 mA current signal
		1	4 to 20 mA current signal

### 5.5 Minimum cycle time

The minimum cycle time specifies how far the bus cycle can be reduced without communication errors occurring. It is important to note that very fast cycles reduce the idle time available for handling monitoring, diagnostics and acyclic commands.

Minimum cycle time
250 μs

### 5.6 Minimum I/O update time

The minimum I/O update time specifies how far the bus cycle can be reduced so that an I/O update is performed in each cycle.

Minimum	/O update time
	400 μs