## **Product datasheet** Characteristics

## XVBC9M **INDICATING BANK BUZZER 230VAC** +OPTIONS



#### Main

i i i i i i i i i i i i i i i i i i i		
Range of product	Harmony XVB Universal	
Product or component type	Indicator bank	1
Beacon or indicator bank unit type	Audible unit	
Mounting diameter	70 mm	
Component name	XVBC	
Noise level	7090 dB at 1 m	
[Us] rated supply voltage	120230 V AC	

#### Contractual warranty

#### Complementary

ony XVB Universal tor bank le unit n 2 0 dB at 1 m 230 V AC onths nuous or intermittent buzzer mer assembly, up to 5 units v clamp terminals: <= 1 x 1.5 mm <sup>2</sup> with cable end 'conforming to IEC 60947-1 1.1 Un conforming to IEC 60947-5-1 mA sonforming to IEC 60947-1 1z n n 1 1 1 1 1 1 1 1 1 1 1 1 1
ony XVB Universal ator bank ile unit n C O dB at 1 m 230 V AC
ony XVB Universal ator bank le unit n C O dB at 1 m 230 V AC
ony XVB Universal ator bank lle unit n C O dB at 1 m 230 V AC
ony XVB Universal ator bank le unit m C 0 dB at 1 m 230 V AC
ator bank lle unit n C 0 dB at 1 m 230 V AC
n C O dB at 1 m C C C C C C C C C C C C C C C C C C C
n C O dB at 1 m 230 V AC
C dB at 1 m 230 V AC
0 dB at 1 m 230 V AC
230 V AC
onths
onths
onths
nuous or intermittent buzzer
omer assembly, up to 5 units
v clamp terminals: <= 1 x 1.5 mm <sup>2</sup> with cable end
conforming to IEC 60947-1
.1.1 Un conforming to IEC 60947-5-1
nA
conforming to IEC 60947-1
Hz
n
n
n
(g

#### Environment

Product	certifications	5




	CSA C22-2 No 14 GOST UL 508
Standards	EN/IEC 60947-5-1
Protective treatment	TC
Ambient air temperature for storage	-4070 °C
Ambient air temperature for operation	-2550 °C
Class of protection against electric shock	Class II on base unit conforming to IEC 61140 Class I on support tube conforming to IEC 61140
IP degree of protection	IP65 on fixing base XVBZ0. conforming to IEC 60529 IP66 on base unit conforming to IEC 60529
NEMA degree of protection	NEMA 4X (indoor) conforming to UL 508

### Indicator Bank with "Flash" Discharge Tube Unit

#### Dimensions

Below drawing shows the minimum configuration of the product. Select the number of stages according to the product characteristics in order to get b dimension.



- Base unit XVBC07, to be ordered separately (1)
- (2) (3) Illuminated or audible signalling unit
- "Flash" unit, to be ordered separately


Number of illuminated or audible signalling units other than "flash" tube	b in mm	b in in.
1	295	11.61
2	358	14.09
3	421	16.57
4	484	19.06



### Indicator Bank with "Flash" Discharge Tube Unit

#### Dimensions

Below drawing shows the minimum configuration of the product. Select the number of stages according to the product characteristics in order to get b dimension.



- (1) Base unit XVBC07, to be ordered separately
- Illuminated or audible signalling unit
- (2) (3) "Flash" unit, to be ordered separately

Number of illuminated or audible signalling units other than "flash" tube	b in mm	b in in.
1	295	11.61
2	358	14.09
3	421	16.57
4	484	19.06

**Product datasheet** 

# XVBC9M


**Technical Description** 

#### **Indicator Bank**

#### Adjustment of Audible Signal

By means of 4 microswitches located in the base of the buzzer:

- 2 switches marked 1 and 2 for selecting continuous or intermittent mode (Hz).
- 2 switches marked 3 and 4 for selecting the power (dB) of the audible signal.



Position of microswitches			Setting	
1	2		Mode	
1	1		continuous: 2.8 kHz	
1	0		continuous: 2.8 kHz	
0	1		intermittent: 5 Hz	
0	0		intermittent: 1 Hz	
Position of microswitches		Setting		
3	4	Power		
1	1	90 dB		
0	1	85 dB		
1	0	80 dB		
0	0 70 0		70 dB	

