# Data Sheet | Item Number: 211-811

Marker; for Smart Printer; for use in nozzles; Length: 12 mm; white

https://www.wago.com/211-811







Color: white

Technical data	
Marking method	Thermal transfer
Marking	plain
Delivery form	Roll
Delivery form configuration	2,500 markers/reel
Printing device	Smart Printer (thermal transfer printer)

Physical data	
Depth	0.26 mm
Length	12 mm
Marking surface	4 x 12 mm

Mechanical data	
Mounting type	Pushing in
Smear resistance	in conjunction with 258-5005 Ink Ribbon

Material data	
Color	white
Material	Polyester
UV resistance	EN 60068-2-5:2010 Procedure B
Adhesive information	without adhesive
Halogen-free	Yes
Weight	221 g
Fire load	0 MJ

# Data Sheet | Item Number: 211-811

https://www.wago.com/211-811




Environmental requirements	
Ambient temperature (storage)	+10 +22 °C
Ambient temperature (operation)	-20 +80 °C

Environmental requirements	
Ambient temperature (storage)	+10 +22 °C
Ambient temperature (operation)	-20 +80 °C
Relative humidity	40 50 %

Commercial data	
Product Group	2 (Terminal Block Accessories)
PU (SPU)	1 pcs
Packaging type	Box
Country of origin	DE
GTIN	4050821674979
Customs tariff number	39269097900

Product classification	
UNSPSC	55121612
eCl@ss 10.0	27-40-04-01
eCl@ss 9.0	27-40-06-29
ETIM 9.0	EC001530
ETIM 8.0	EC001530
ECCN	NO US CLASSIFICATION

Environmental Product Compliance	
RoHS Compliance Status	Compliant,No Exemption



Documentation			
Operating Instructions			
211-821 Information on printing material	1 28.08.2020	pdf 1248.71 KB	<u>↓</u>

## Data Sheet | Item Number: 211-811

https://www.wago.com/211-811



## 1 Compatible Products

## 1.1 Optional Accessories

#### 1.1.1 Marking

## 1.1.1.1 Marking sleeve



#### Item No.: 211-812

Nozzles; Length: 12 mm; For the use of 211-811; halogen-free; Cable outer diameter: 1.4 ... 5.0 mm; transparent




#### Item No.: 211-813

Nozzles; Length: 12 mm; For the use of 211-811; halogen-free; Cable outer diameter: 5.0 ...11.0 mm; transparent

## **Installation Notes**

#### Marking







Slide the marker into the marking sleeve receptacle. Replacing the marker is also possible after the conductor has been terminated.



Slide the marker through the marker slot up to the end of the sleeve.



Then remove the rest of the card by twisting it off.

Subject to changes. Please also observe the further product documentation!